



## BALLASTS

### **TYPE 82833**

#### **200W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—90 to 230 Volts AC., 50 or 60 Hz 5A max.  
**CONTROL SWITCHES:** ON and OFF rocker switch mounted on Ballast control panel. Maybe reignited when hot.  
**CIRCUIT PROTECTION:** Fuse, 5 Amp.  
**CABLE:** 5 ft., Attached to Ballast.  
**CONSTRUCTION:** Solid and slotted sheet aluminum.  
**FINISH:** Anodized Aluminum.  
**SIZE:** 10" x 6<sup>1</sup>/<sub>4</sub>" x 3".  
**BALLAST WEIGHT:** 5 lbs.



### **TYPE 82850**

#### **200W ELECTRONIC DC SQUAREWAVE BALLAST**

**RATING:** Input—24 to 32 Volts DC., 11A max.  
**CONTROL SWITCHES:** Inline ON and OFF rocker switch mounted on power cord.  
**CIRCUIT PROTECTION:** Internal 15 Amp Fuse.  
**CABLE:** 4 ft., Attached to Ballast.  
**CONSTRUCTION:** Solid and slotted sheet aluminum.  
**FINISH:** Anodized Aluminum.  
**SIZE:** 7" x 4<sup>1</sup>/<sub>4</sub>" x 3".  
**BALLAST WEIGHT:** 3 lbs.



### **TYPE 82926**

#### **400W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—90 to 260 Volts AC., 50 or 60 Hz 7.5A max.  
**CONTROL SWITCHES:** ON and OFF rocker switch mounted on Ballast control panel. Maybe reignited when hot.  
**CIRCUIT PROTECTION:** Fuse, 10 Amp.  
**CABLE:** 5 ft., Attached to Ballast.  
**CONSTRUCTION:** Solid and slotted sheet aluminum.  
**FINISH:** Anodized Aluminum/Powder Coated Enamel.  
**SIZE:** 11" x 7<sup>1</sup>/<sub>2</sub>" x 6<sup>1</sup>/<sub>4</sub>".  
**BALLAST WEIGHT:** 8 lbs.



### **TYPE 64970**

#### **575W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—90 to 260 Volts AC., 50 or 60 Hz 8.2A max.  
**CONTROL SWITCHES:** ON and OFF rocker switch mounted on Ballast control panel. Maybe reignited when hot.  
**CIRCUIT PROTECTION:** Fuse, 10 Amp.  
**CABLE:** 5 ft., Attached to Ballast.  
**CONSTRUCTION:** Solid and slotted sheet aluminum.  
**FINISH:** Anodized Aluminum/Powder Coated Enamel.  
**SIZE:** 8.25" x 4.25" x 7.5".  
**BALLAST WEIGHT:** 4 lbs.



# Mole-Richardson Co.

## BALLASTS



### **TYPE 68220**

#### **800W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—90 to 220 Volts AC., 50 or 60 Hz 9.1A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel. Maybe reignited when hot.

**CIRCUIT PROTECTION:** Fuse, 15 Amp.

**CABLE:** 5 ft., Attached to Ballast.

**CONSTRUCTION:** Solid and slotted sheet aluminum.

**FINISH:** Anodized Aluminum.

**SIZE:** 9" x 8½" x 5".

**BALLAST WEIGHT:** 6 lbs.



### **TYPE 63765**

#### **575W/1,200W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—90 to 230 Volts AC., 50 or 60 Hz 15A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel. Maybe reignited when hot.

**CIRCUIT PROTECTION:** Double pole circuit breaker and red indicator light.

**CABLE:** 6 ft., Attached to Ballast.

**CONSTRUCTION:** Solid sheet aluminum with aluminum fins

**FINISH:** Anodized Aluminum.

**SIZE:** 11½" x 9" x 7".

**BALLAST WEIGHT:** 17 lbs.



### **TYPE 638185**

#### **2,500W/4,000W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—95 to 260 Volts AC., 50 or 60 Hz 33.6A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel.

**CIRCUIT PROTECTION:** Double pole circuit breaker and red indicator light.

**CABLE:** X ft., Attached to Ballast.

**CONSTRUCTION:** Solid and slotted sheet aluminum.

**FINISH:** Anodized Aluminum.

**SIZE:** 15" x 10½" x 9½".

**BALLAST WEIGHT:** 31 lbs.

### **TYPE 66569**

#### **4,000W/6,000W ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—195 to 260 Volts AC., 50 or 60 Hz 65A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel.

**CIRCUIT PROTECTION:** Circuit breaker.

**CABLE:** Type 665XX 5 ft., Detachable with Veam type connector with customer specified connector.

**CONSTRUCTION:** Solid and perforated sheet aluminum with cart

**FINISH:** Anodized Aluminum.

**SIZE:** 22" x 20½" x 27". (48.5" high with handle raised)

**BALLAST WEIGHT:** 95 lbs.



## BALLASTS

### **TYPE 66065**

**12,000W/18,000W**

#### **ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—208 to 240 Volts AC., 50 or 60 Hz 80A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel.

**CIRCUIT PROTECTION:** Double pole circuit breaker and red indicator light.

**CABLE:** Type 66066 5 ft., Detachable with Veam type connector with customer specified connector.

**CONSTRUCTION:** Solid and perforated sheet aluminum with cart

**FINISH:** Anodized Aluminum.

**SIZE:** 30" x 20½" x 27". (48.5" high with handle raised)

**BALLAST WEIGHT:** 140 lbs.



3

18

### **TYPE 680229**

**12,000W/18,000W/24,000W**

#### **ELECTRONIC AC SQUAREWAVE BALLAST**

**RATING:** Input—208 to 240 Volts AC., 50 or 60 Hz 80A max.

**CONTROL SWITCHES:** ON and OFF push button mounted on Ballast control panel.

**CIRCUIT PROTECTION:** Double pole circuit breaker and red indicator light.

**CABLE:** Type 66066 5 ft., Detachable with Veam type connector with customer specified connector.

**CONSTRUCTION:** Solid and perforated sheet aluminum with cart

**FINISH:** Anodized Aluminum.

**SIZE:** 30" x 20½" x 27". (48.5" high with handle raised)

**BALLAST WEIGHT:** 140 lbs.